

Figure 1

FIG. 4 is a perspective view of a handheld electronic device 400, such as a PDA, showing a screen 406 displaying a menu of applications. The device 400 includes a display screen 406, a keypad 404, and various control buttons 402, 408, 410, 412, 414, 416, 418, 420, 422, 424, 426, 428, 430, 432, 434, 436, 438, 440, 442, 444. The screen 406 shows a time display of 3:07 pm and a list of applications including Address, Calc, Date Book, Expense, Graffiti, HotSync, Mail, Memo Pad, Prefs, Security, The Scan, and To Do List. The keypad 404 includes a home button, a search button, and a numeric keypad. The control buttons 402, 408, 410, 412, 414, 416, 418, 420, 422, 424, 426, 428, 430, 432, 434, 436, 438, 440, 442, 444 are arranged around the screen 406 and the keypad 404.




Figure 4




Figure 2




Figure 3




Figure 5




Figure 6




Figure 7




Figure 8






Figure 9




Figure 10




Figure 11



Figure 12



Figure 13





Figure 14




Figure 15




Figure 16